

INTENDED FOR USE BY PROFESSIONAL EQUIPMENT OPERATORS

OPERATING INSTRUCTIONS



908 W. Main • P.O. Box 368

Laurel, MT USA 59044

(1) 800-548-7341

(1) 406-628-8231

www.wpg.com



**READ AND UNDERSTAND BEFORE
OPERATING THIS EQUIPMENT**



**QUADRA-TILT LIFTER
WITH ADJUSTABLE PAD
FRAME, AC-VOLTAGE**

Model numbers: MTA4LP6FAC, MTA6LP6FAC (*shown*)

Original Instructions © Wood's Powr-Grip Co., Inc.

TABLE OF CONTENTS

SPECIFICATIONS	3
SAFETY	5
OPERATING FEATURES.....	6
ASSEMBLY	7
INTENDED USE	9
LOAD CHARACTERISTICS.....	9
INDIRECT LOADING	10
OPERATING ENVIRONMENT	10
DISPOSAL OF THE LIFTER	10
OPERATION.....	11
BEFORE USING THE LIFTER.....	11
Taking Safety Precautions	11
Performing Inspections and Tests	11
TO POSITION MOVABLE PAD ARMS.....	12
TO ATTACH THE PADS TO A LOAD	13
Generating Airflow.....	13
Positioning the Lifter on the Load.....	13
Reading the Vacuum Gauge.....	14
TO LIFT AND MOVE THE LOAD.....	15
About the Tilt Linkage	15
Interpreting the Vacuum Gauge	15
Monitoring the Vacuum Gauge.....	15
Controlling the Lifter and Load	16
In Case of a Power Failure.....	16
TO TILT THE LOAD	17
TO RELEASE THE PADS FROM THE LOAD	18
AFTER USING THE LIFTER.....	18
Storing the Lifter	19
Transporting the Lifter	19
INSPECTIONS AND TESTS.....	20
INSPECTION SCHEDULE	20
TESTING	21


Lifter/Load Compatibility Test.....	21
Operational Tests	22
Vacuum Test.....	22
Rated Load Test.....	23
MAINTENANCE	24
VACUUM PAD MAINTENANCE.....	24
Pad-to-Load Friction Coefficient	24
Pad Inspection	24
Pad Cleaning	25
REPLACEMENT PARTS.....	26
REGISTRATION AND LIMITED WARRANTY	27
TO REGISTER THIS WPG PRODUCT	27
ABOUT THE LIMITED WARRANTY	27
Obtaining Warranty Service or Repair Service.....	27

SPECIFICATIONS

Product Description	Designed for use with hoisting equipment, MTA-LP6FAC lifters support loads using vacuum and manipulate loads using mechanically assisted, manual 90° tilt motions.	
Model Number	MTA4LP6FAC	MTA6LP6FAC
 Maximum Load Capacity^{1, 2}	Per pad: 50 lbs (22.5 kg) Total: 200 lbs (90 kg)	Per pad: 50 lbs (22.5 kg) Total: 300 lbs (135 kg)
 Lifter Weight	65 lbs (30kg)	70 lbs (32kg)
Vacuum Pads³ (standard rubber)	Four 6" (15 cm) nominal diameter, low profile (Model LP6F)	Six 6" (15 cm) nominal diameter, low profile (Model LP6F)
Pad Spread	(to outer edges)	
Length	Minimum: 13" (327 mm) Maximum: 39" (991 mm)	
Width	Minimum: 9" (226 mm) Maximum: 30" (760 mm)	
Power Source	See serial number plate for specific AC voltage, frequency and amperage.	
 Tilt Capability	Manual, 90°, with four-bar tilt linkage that provides mechanical advantage	
Movable Pad Arms	Manual, 210°, with automatic locking every 30°	
 Product Options	Available with 2" (5 cm) Pad Spacers. See separate instructions about other options.	
 Operating Elevation	Up to 6,000' (1,828 m)	
 Operating Temperatures	32° — 104° F (0° — 40° C)	
Service Life	16,000 lifting cycles, when used and maintained as intended ⁴	
ASME Standard BTH-1	Design Category "B", Service Class "0"	
Troubleshooting Guide	TST-016_GENERIC_LEAK_TEST_rev_2014-086	

- 1..... The Maximum Load Capacity is rated and verified at a vacuum of 16" Hg (-54 kPa) on clean, smooth, nonporous flat surfaces with a friction coefficient of 1. Rating is verified by testing on polycarbonate (or metal with a painted surface) with a coefficient of friction similar to plain (non-coated) glass and a surface temperature at approx. 70° F (21° C).
- 2..... Pad compound, load rigidity, strength, surface conditions, overhang, angle, center of gravity and temperature affect lifting capacity. A "qualified person" should evaluate the effective lifting capacity for each use (see definition under "[Rated Load Test](#)").
- 3..... Available with [other rubber compounds](#) for special purposes.
- 4..... Vacuum pads, filter elements and other wear-out items are excluded.

SPECIFICATIONS



Note: A standard MTA6LP6FAC is shown.

SAFETY



Wear personal protective equipment that is appropriate for the load material. Follow trade association guidelines.



Do not remove or obscure safety labels.



Do not make any modifications to the lifter. Modifying the lifter will void the "LIMITED WARRANTY".



Use the lifter only in an approved "OPERATING ENVIRONMENT" (see "INTENDED USE").



Make sure to consider all possible effects of "INDIRECT LOADING" on lifting capacity (see "INTENDED USE").



Do not use a lifter that is damaged, malfunctioning, or missing parts.



Do not use a lifter if the sealing edge of any vacuum pad is cut or otherwise damaged.



Do not use a lifter to lift cracked or broken glass.



Do not exceed the Maximum Load Capacity or lift loads the lifter is not designed for (see "INTENDED USE").



Do not use a lifter if the Maximum Load Capacity or any safety label appears to be missing or obscured.



Make sure the contact surfaces of loads and vacuum pads are clean before attaching lifters (see "MAINTENANCE").



Position vacuum pads correctly on the loads before lifting (see "OPERATION").



Do not lift a load if any vacuum indicator shows inadequate vacuum.



Keep unauthorized personnel away from the lifter, to avoid injury in case of an unintended load release.



Do not touch the vacuum release controls during a lift.



Do not allow people to ride on the lifter or the load.



Do not lift a load higher than necessary or leave suspended loads unattended.




Do not position a loaded or unloaded lifter over people.



Before servicing a powered lifter, place the power control in the inactive position and, when possible, disconnect the power source.

OPERATING FEATURES

Features shown here are underlined> on their first appearance in each section following.



- | | |
|--------------------|-------------------------|
| 1 LIFT POINT | 2 VACUUM GAUGE |
| 3 LIFT BAR | 4 VACUUM PAD |
| 5 VACUUM PUMP | 6 AIR FILTER |
| 7 PAD FRAME | 8 VACUUM RELEASE BUTTON |
| 9 CONTROL HANDLE | 10 PAD ARM LIMIT DISK |
| 11 PAD ARM RELEASE | 12 POWER SWITCH |

Note: A standard MTA6LP6FAC is shown. Although some of the following photos do not show this specific lifter, they all illustrate how this kind of lifter functions.

For information about specific parts, see [“REPLACEMENT PARTS”](#) and/or any separate instructions for Product Options.

ASSEMBLY

- 1) Remove all shipping materials and save them with the shipping container for future use.
- 2) Connect the power cable:




Make sure power source has ground fault circuit interrupter.

- 2.1) Wire the female connector provided to an appropriate power source, as indicated on the label attached.




Wiring must be performed by qualified service personnel, taking all appropriate safety precautions.

- 2.2) Route the power cable so that it does not become damaged during operation.
- 2.3) Insert the power cable's male connector into the female connector and twist to secure them together (figs. 2A-B).



- 3) Suspend the lifter from appropriate hoisting equipment:

- 3.1) Select a crane and/or hoist rated for the Maximum Load Capacity plus the Lifter Weight.



Note: Any lifter use must comply with all statutory or regulatory standards for hoisting equipment in your region.

- 3.2) Attach the hoisting hook to the lift point (figs. 3A-B).



Make sure hook has restraining latch (see arrow in fig. 3B).



Note: Use rigging (fig. 3C) as needed to make sure the hook does not interfere with the load.



Only use rigging rated for Maximum Load Capacity plus Lifter Weight.

- 3.3) Use the hoisting equipment to remove the lifter from the shipping container. Avoid damaging the vacuum pads.

ASSEMBLY

- 4) Remove the pad covers (fig. 4A) and save them for future use.

4A



- 5) Perform tests as required under “**TESTING**”.

LOAD CHARACTERISTICS

Make sure the vacuum lifter is intended to handle each load according to these requirements:



Do NOT lift explosives, radioactive substances or other hazardous materials.



- The load weight must not exceed the Maximum Load Capacity.
- The load must be a single piece of relatively nonporous material with a flat and relatively smooth contact surface.^{1, 2} To determine whether the load is too porous or rough, perform the “[Lifter/Load Compatibility Test](#)”.
- The load's contact surface must be able to obtain a friction coefficient of 1 with the lifter's vacuum pads (see “[Pad-to-Load Friction Coefficient](#)”). Otherwise, the capacity should be derated appropriately.
- The load's surface temperature must not exceed 150° F (66° C).³
- The load's *minimum* length and width are determined by the current Pad Spread (see “SPECIFICATIONS”).
- The load's *maximum* length and width are determined by its allowable overhang.⁴
- 1½" (3.8 cm) is the allowable thickness at Maximum Load Capacity.⁵ The load must be positioned correctly on the lifter (see “OPERATION”). If not, the allowable load thickness would be reduced.⁶



Note: Standard vacuum pads can stain or deform load surfaces with light colors or soft coatings. Test such surfaces for damaging effects before using the lifter on them.⁷

1..... Although concave vacuum pads can also attach to some curved loads, curvature can reduce lifting capacity. Contact WPG for more information.

2..... A “single piece” of material includes curtainwall assemblies, unitized glazing systems and similar construction units.

3..... Vacuum pads made from a heat-resistant rubber compound can enable you to lift loads with higher surface temperatures. Contact WPG or an authorized dealer for more information.

4..... The allowable overhang is the amount of load material that can extend sideways beyond the vacuum pad without breaking or otherwise being damaged. This depends on the load material, its thickness, and the angle of handling (if any). Since every material has different physical properties, the allowable overhang must be evaluated separately for each load type. Contact WPG or an authorized dealer for more information.

5..... However, the allowable thickness increases as load weight decreases. Contact WPG for more information.

6..... **Pad Spacers can reduce the stability of upright loads and allowable load thickness.** Contact WPG for more information.

7..... Alternative rubber compounds are available for these purposes. Contact WPG or an authorized dealer for more information.

INDIRECT LOADING

Make sure to account for dynamic loading or other inadvertent loading that can negatively affect lifting capacity, such as:

- Weight amplification that results when a loaded vacuum lifter abruptly starts/stops moving, changes direction or bounces up and down (eg, when a telehandler transports a loaded lifter across rough terrain).
- External force that effectively increases the weight of a lifter's attached load (eg, when a load of sheet material reacts to wind gusts).



Indirect loading can reduce lifting capacity.

OPERATING ENVIRONMENT

Make sure the lifter is suitable for each work environment, given the following restrictions:

- This lifter is not intended for any environment that is dangerous to the operator or damaging to the lifter. Avoid environments containing explosives, caustic chemicals and other dangerous substances.




Never use lifter in dangerous environments.



Metal particles and similar environmental contaminants could result in vacuum pump failure.

- The work environment is limited by the Operating Elevation and Operating Temperatures.^{1, 2}
- The lifter is not designed to be watertight. Do not use it in rain or other unsuitable conditions.



Moisture can reduce lifting capacity.

CE/UKCA — A secondary positive holding device is required to lift loads on constructions sites or in other “high risk zones” (see EN 13155).

DISPOSAL OF THE LIFTER

After the Service Life of the lifter has ended (see “SPECIFICATIONS”), dispose of it in compliance with all local codes and applicable regulatory standards.

1..... Although lifter use may be possible at higher elevation, lifting capacity is reduced whenever the lifter is unable to attain vacuum in the green range on the vacuum gauge. Contact WPG for more information.

2..... Special provisions may allow the lifter to operate outside the specified temperature range. Contact WPG for more information.

BEFORE USING THE LIFTER

Determine whether the vacuum lifter is capable of each intended task (see “SPECIFICATIONS” and “[INTENDED USE](#)”). Then complete the following preparations:

Taking Safety Precautions

- Be trained in all industry and regulatory standards for lifter operation in your region.
- Follow trade association guidelines about precautions needed for each load material.



Read all directions and safety rules before using lifter.



Always wear appropriate personal protective equipment.

Performing Inspections and Tests

- Follow the “[INSPECTION SCHEDULE](#)” and “[TESTING](#)”.
- Service the air filter whenever its bowl contains liquid or other contaminants, or its element appears dirty (see “AIR FILTER MAINTENANCE” in [SERVICE MANUAL](#)).¹



Examine air filter regularly and service when needed.


1..... Lifters used on wet load surfaces must be equipped with 2 or more filters connected *in series*. See “[OPERATING ENVIRONMENT](#)” for restrictions.

OPERATION


TO POSITION MOVABLE PAD ARMS

Position the movable pad arms to maximize load support and minimize load overhang (see “[LOAD CHARACTERISTICS](#)”):

- 1) Pull and hold the pad arm release (arrow in fig. 1A), to disengage the arm.



- 2) Rotate the arm to the desired position (fig. 2A). Then let go of the pad arm release.



- 3) Continue rotating the arm until it engages at the next stop on the pad arm limit disk.
- 4) Repeat steps 1-3 with other pad arms as needed.

OPERATION

TO ATTACH THE PADS TO A LOAD

Generating Airflow

Place the power switch in the “on” position (fig. 1A), to engage the vacuum pump.



Keep pump running throughout lift.

The lifter is designed for the vacuum pump to run continuously. Placing the power switch in the “off” position during lifter operation could result in a load release and personal injury (see “[In Case of a Power Failure](#)”).



Positioning the Lifter on the Load

- 1) Make sure the contact surfaces of the load and vacuum pads are clean (fig. 1B; see “[Pad Cleaning](#)”).

1B



- 2) Make sure movable pad arms are positioned as desired (see “[TO POSITION MOVABLE PAD ARMS](#)”).
- 3) Center the pad frame on the load (fig. 3B).¹

3B



1..... The lifter is designed to handle the maximum load weight when the load’s center of gravity is positioned within 2" (5 cm) of the pad frame’s center point.


OPERATION

- 4) Make sure all vacuum pads will fit on the load and will be loaded evenly (fig. 4B).



Consult the Per-Pad Load Capacity.

- 5) Place the pads in contact with the load surface until they begin to seal. Make sure all pads seal completely against the load.¹



Reading the Vacuum Gauge

A vacuum gauge shows the current vacuum level in positive inches of Hg and negative kPa:

- *Green range* (≥ 16 " Hg [≤ -54 kPa]): Vacuum level is sufficient to lift the maximum load weight (fig. 1A).
- *Red range* (< 16 " Hg [> -54 kPa]): Vacuum level is **not** sufficient to lift the maximum load weight (fig. 2A).

1A



2A



If it takes more than 5 seconds for the vacuum level to reach 5" Hg (-17 kPa), press on any vacuum pad that has not yet sealed.

Once the pads have sealed, the lifter should be able to maintain sufficient vacuum for lifting, except when used above the maximum Operating Elevation.² If it does not, perform the "Vacuum Test".

1..... Although a vacuum pad may become distorted during shipping or storage, this condition should correct itself with continued use.

2..... If the lifter is used above the maximum Operating Elevation (see "SPECIFICATIONS"), it may not be able to maintain sufficient vacuum for lifting. Contact WPG for more information.

OPERATION

TO LIFT AND MOVE THE LOAD

About the Tilt Linkage

The tilt linkage minimizes operator effort and automatically holds a balanced load in either the upright or the flat position. However, an unbalanced load may tilt unexpectedly, resulting in load damage or personal injury.

To minimize these risks, make certain *before lifting any load* that it has appropriate “**LOAD CHARACTERISTICS**” and is attached to the vacuum lifter as previously directed.



Unbalanced loads may tilt unexpectedly during lifter operation.



Make sure load is positioned correctly on lifter.

Interpreting the Vacuum Gauge



Vacuum is sufficient to lift the Maximum Load Capacity whenever the vacuum gauge registers in the green range.



Never lift load unless vacuum gauge registers in the green range, because premature lifting could result in load release and personal injury.

Monitoring the Vacuum Gauge

Monitor the vacuum gauge (fig. 1B) throughout the entire lift.

1B



Make sure the vacuum gauge remains completely visible.

The vacuum pump runs continuously to maintain sufficient vacuum for lifting the maximum load weight.

However, if the ***vacuum gauge shows a level less than 16" Hg (greater than -54 kPa):***

- 1) Keep everyone away from a suspended load until it can be safely lowered to a stable support.



Stay clear of any suspended load while gauge warns of insufficient vacuum.


- 2) Stop using the lifter until the cause of the vacuum loss can be identified: Conduct the “**Pad Inspection**” and perform the “**Vacuum Test**”.
- 3) Correct any faults before resuming normal operation of the lifter.

Controlling the Lifter and Load

When the lifter is ready, use the hoisting equipment to raise the lifter and load as needed.

Use the control handles (circled in fig. 1A) to keep the lifter and load in the required position.

Once there is enough clearance, you may move the load as required.



In Case of a Power Failure

Although the lifter is designed to support the load for at least 5 minutes without power, this depends on many factors, including the “[LOAD CHARACTERISTICS](#)” and the condition of the vacuum pads (see “[VACUUM PAD MAINTENANCE](#)”).

If a power failure occurs, keep everyone away from a suspended load until it can be safely lowered to a stable support. Correct any faults before resuming normal operation of the lifter.




Stay clear of any suspended load during power failure.

OPERATION

TO TILT THE LOAD




Keep hands and fingers away from tilt linkage.




- 1) Make sure the load has enough clearance to tilt without contacting anyone or anything.
- 2) Use the tilt control handle (see arrows in figs. 2A-B) to keep the load under control at all times.



Unbalanced loads may tilt unexpectedly.



2A



2B

- 3) Lift upward or press downward on the tilt control handle to tilt the load as desired (figs. 2A-B).¹

Note: See “LOAD CHARACTERISTICS” about allowable load overhang.

A load with overhang may force you to release the tilt control handle as the load approaches the flat position. In this case, use hand cups (circled in fig. 3A) or other appropriate means to control the load.

3A



1..... Due to the tilt linkage design, load force on the control handle changes direction during the tilt.

OPERATION

TO RELEASE THE PADS FROM THE LOAD



Make sure load is at rest and fully supported before releasing vacuum pads.

- 1) Push the vacuum release button (|→) — fig. 1A), to break the vacuum seal.



Do not move lifter until pads release completely, because such movement could result in load damage or personal injury.

- 2) After the load is successfully released, move the lifter away. Otherwise, the lifter will automatically reattach.
- 3) Before you lift another load, perform the Every-Lift Inspection (see “[INSPECTION SCHEDULE](#)”).



AFTER USING THE LIFTER

- 1) Place the power switch in the “off” position (fig. 1B).




- 2) Use the hoisting equipment to lower the vacuum lifter gently onto a stable support. Then detach the hoisting hook from the lift point.

***Caution:* Do not set the lifter on surfaces that could soil or damage vacuum pads.**

OPERATION

Storing the Lifter

- 1) Disconnect the electrical connectors (figs. 1A-B).



- 2) Use the covers supplied to keep the vacuum pads clean (fig. 2A).



CE/UKCA — To prevent the lifter from tipping over on relatively horizontal surfaces, place the vacuum pads facedown on a clean, smooth, flat surface. Then lower the lift bar and place a support under the lift point.

- 3) Store the lifter in a clean, dry location.

Transporting the Lifter

Secure the lifter in the original shipping container with the original shipping materials or equivalent.

INSPECTIONS AND TESTS

INSPECTION SCHEDULE

Perform inspections according to the following frequency schedule. If any fault is found, correct it and perform the next most frequent inspection before using the vacuum lifter.

Note: If a lifter is used less than 1 day in a 2-week period, perform the Periodic Inspection before using it.

Action	Every Lift	Frequent ¹ (every 20-40 hrs)	Periodic ² (every 250-400 hrs)
Examine <u>vacuum pads</u> for contaminants or damage (see “Pad Inspection”).	✓	✓	✓
Examine load surface for contaminants or debris.	✓	✓	✓
Examine controls and indicators for damage.	✓	✓	✓
Examine lifter’s structure for damage.		✓	✓
Examine vacuum system for damage (including <u>vacuum pads</u> , fittings and hoses).		✓	✓
Examine <u>air filter</u> for conditions requiring service (see “AIR FILTER MAINTENANCE” in SERVICE MANUAL).		✓	✓
Perform “Vacuum Test” .		✓	✓
Check for unusual vibrations or noises while operating lifter.		✓	✓
Examine entire lifter for evidence of: • looseness, excessive wear or excessive corrosion • deformation, cracks, dents to structural or functional components • cuts in vacuum pads or hoses • any other hazardous conditions			✓
Inspect entire electrical system for damage, wear or contamination that could be hazardous, in compliance with all local codes and regulatory standards. Caution: Use appropriate cleaning methods for each electrical part, as specified by codes and standards. Improper cleaning can damage parts.			✓

1..... The Frequent Inspection is also required whenever the lifter has been out of service for 1 month or more.

2..... The Periodic Inspection is also required whenever the lifter has been out of service for 1 year or more. Keep a written record of all Periodic Inspections. If necessary, return the lifter to WPG or an authorized dealer for repair (see [“REGISTRATION AND LIMITED WARRANTY”](#)).

TESTING

Perform the following test to determine whether or not a load surface is too porous or rough:

Lifter/Load Compatibility Test¹

- 1) Make sure the vacuum generating system is functioning correctly (see “[Vacuum Test](#)”).
- 2) Thoroughly clean the load surface and the vacuum pads (see “[Pad Cleaning](#)”).
- 3) Place the load in the upright position on a stable support.
- 4) Attach the vacuum pads to the load as previously directed.
- 5) After the vacuum level appears in the green range on the vacuum gauge, place the power switch in the “off” position (○).
- 6) Raise the load a minimal distance, to make sure it is supported by the lifter.
- 7) Watch the vacuum gauge: ***Starting from a vacuum level of 16" Hg (-54 kPa), the lifter must maintain a vacuum level greater than 12" Hg (less than -41 kPa) for 5 minutes.***² If not, lifting this load requires additional precautions (eg, a load sling). Contact WPG for more information.
- 8) Lower the load *after* 5 minutes or *before* the vacuum level diminishes to 12" Hg (increases to -41 kPa).



Take precautions in case load should fall during test.

1..... The “[Pad-to-Load Friction Coefficient](#)” can affect the outcome of this test.

2..... Under CE and UKCA requirements, the lifter must maintain a vacuum level ***greater than 8" (less than -27 kPa)***.

INSPECTIONS AND TESTS

Perform the following tests before placing the lifter in service *initially, following any repair,* when directed in the “*INSPECTION SCHEDULE*”, or *whenever necessary*:

Operational Tests

Test all features and functions of the lifter (see “OPERATING FEATURES” and “OPERATION”).

Vacuum Test

- 1) Clean the faces of the vacuum pads (see “*Pad Cleaning*”).
- 2) Use a test load with weight equal to the Maximum Load Capacity, a clean, smooth, nonporous surface and other appropriate “*LOAD CHARACTERISTICS*”.¹ 
- 3) Attach the lifter to the test load as previously directed.
- 4) After the vacuum level appears in the green range on the vacuum gauge, raise the load a minimal distance and place the power switch in the “off” position (○).

 ***Take precautions in case load should fall during test.***
- 5) Watch the vacuum gauge: *The vacuum level should not decrease by more than 4" Hg (increase by more than 14 kPa) in 5 minutes.*
- 6) Lower the load after 5 minutes or whenever a lifter fails the test, and release the load as previously directed.

 ***Never use lifter that has failed test.***
- 7) Qualified service personnel must correct any fault in the vacuum system before returning the lifter to service.

 ***This service must be performed by qualified service personnel.***

1..... The load should have either a flat surface or no more curvature than the lifter is designed for, if any.

INSPECTIONS AND TESTS

Rated Load Test¹

The following steps must be performed or supervised by a qualified person:²

- 1) Use a test load that weighs 125% ($\pm 5\%$) of the Maximum Load Capacity and has the appropriate “LOAD CHARACTERISTICS”. 
- 2) Attach the vacuum pads to the load as previously directed.
- 3) Position the load to produce the greatest stress on the lifter consistent with “INTENDED USE”.
- 4) Raise the load a minimal distance and leave it suspended for 2 minutes.
- 5) Once the test is completed, lower the load for release as previously directed.
- 6) Inspect the lifter for any stress damage, and repair or replace components as necessary to successfully pass the test.
- 7) Prepare a written report of the test and keep it on file.



Take precautions in case load should fall during test.



Never use lifter that has failed test.

1..... An equivalent simulation may also be used. Contact WPG for more information.

2..... A “qualified person” has successfully demonstrated the ability to solve problems relating to the subject matter and work, either by possessing a recognized degree in an applicable field or a certificate of professional standing, or by possessing extensive knowledge, training and experience.

Note: Refer to **SERVICE MANUAL #35275** when applicable.

VACUUM PAD MAINTENANCE

Pad-to-Load Friction Coefficient

The friction coefficient represents the lifter's ability to resist load slippage. The Maximum Load Capacity is based on a friction coefficient of 1, as determined by testing of clean, new, standard rubber vacuum pads on clean, dry, regular glass. ***If the lifter is used under any other conditions, a qualified person must first determine the effective lifting capacity.***¹



Long-term exposure to heat, chemicals or UV light can damage vacuum pads. Replace pads every 2 years or more often when necessary.

Pad Inspection


Inspect each vacuum pad (fig. 1A) according to the “**INSPECTION SCHEDULE**” and correct the following faults before using the lifter (see “**REPLACEMENT PARTS**”, when applicable):

- Contaminants on the face (item 1 in fig. 1A) or sealing edges (item 2 in fig. 1A).
- Filter screen (item 3 in fig. 1A) missing from face.



Replace any pad that has damaged sealing edges.

- Nicks, cuts, deformation or abrasions in sealing edges.
- Wear, stiffness or glaze.



1..... A “qualified person” has successfully demonstrated the ability to solve problems relating to the subject matter and work, either by possessing a recognized degree in an applicable field or a certificate of professional standing, or by possessing extensive knowledge, training and experience.

Pad Cleaning

- 1) Regularly clean the face of each vacuum pad (fig. 1A), using soapy water or other mild cleansers to remove oil, dust and other contaminants.



Never use harsh chemicals on vacuum pad.

Solvents, petroleum-based products (including kerosene, gasoline and diesel fuel) or other harsh chemicals can damage vacuum pads.



Never use rubber conditioners on vacuum pad.

Many rubber conditioners can leave a hazardous film on vacuum pads.

- 2) Prevent liquid from entering the vacuum system through the suction hole on the pad face.
- 3) Wipe each pad face clean, using a clean sponge or lint-free cloth to apply the cleanser.¹
- 4) Allow each pad to dry completely before using the lifter.

1A



¹..... A brush with bristles *that do not harm rubber* can help remove contaminants clinging to sealing edges. If these cleaning methods are not successful, contact WPG or an authorized dealer for assistance.

REPLACEMENT PARTS

Stock No.	Description	Qty.
97461	Pad Spacer – 2" (5 cm) (option)	4 / 6
65440TR	Vacuum Hose – 0.245" ID x 3/8" OD – Transparent Red	**
65440	Vacuum Hose – 1/4" ID x 3/8" OD – Red	*
65438	Vacuum Hose – 1/8" ID x 1/4" OD – White	*
65119MM	Flanged Bushing (for tilt linkage)	8
65011	Pad Spring	4 / 6
65011AM	Pad Arm Release Spring	4
53132	Hose Fitting – Tee – 5/32" ID	4
53126	Pad Fitting – Tee – 3/64" ID	0 / 1
53120	Pad Fitting – Elbow – 3/64" ID	4 / 5
49430T	Vacuum Pad – Model LP6F / 6" (15 cm) Diameter – Low Profile	4 / 6
49122	End Plug – 2" x 2" x 1/4" Tubing Size	1
35275	Service Manual – AC	1
29312	Pad Cover – 6" (15 cm) Diameter	4 / 6
15632	Pad Filter Screen – Small	4 / 6
12875	Flat Washer (for tilt linkage)	8
11695	Clamp Collar (for pad arm release)	4
10911	Shoulder Bolt – Socket Head – 1/2" x 5/8" x 3/8-16 Thread (for tilt linkage)	8
10896AM	Shoulder Bolt – Socket Head – 1/4" X 1/2" X 10-32 Thread (for vacuum pads)	16 / 24

* — Length as required; sold by the inch (approx 2.5 cm).

** — For use with barbed fittings only. Do not use with "push-in"-style fittings. Maximum pressure rating: 90 psi @ 75° F (172 kPa @ 24° C). Length as required; sold by the inch (approx 2.5 cm).

See **SERVICE MANUAL #35275** for additional parts.

**SERVICE ONLY WITH IDENTICAL REPLACEMENT PARTS,
AVAILABLE AT WPG.COM OR THROUGH AN AUTHORIZED WPG DEALER**

REGISTRATION AND LIMITED WARRANTY

TO REGISTER THIS WPG PRODUCT

Go to the [PRODUCT REGISTRATION](#) page at [wpg.com](#) and complete the form. Registration keeps you advised of important updates and notifications, and simplifies inquiries to WPG regarding your product. Registration is **not** required to activate your Limited Warranty (see next section).

ABOUT THE LIMITED WARRANTY

Note: Read the [WARRANTY RETURN FORM](#) at [wpg.com](#) for important details about the Limited Warranty.

Wood's Powr-Grip® (WPG) products are warranted to be free from defects in manufacturing and materials for 1 year from the date of purchase.

If a problem develops during the warranty period, follow the instructions below to obtain warranty service. If inspection shows that the product has a defect, WPG will repair or replace the product without charge.



Obtaining Warranty Service or Repair Service

For customers in the U.S. and Canada: Go to the [EXCHANGE PROGRAM, REPAIRS & WARRANTY](#) page at [wpg.com](#) and click the applicable link. Alternatively, you may contact the WPG Technical Service Department (see contact information below).

For customers in all other localities: Contact the WPG Technical Service Department (see contact information below) or your dealer for assistance.

ADDRESS	EMAIL	PHONE
Wood's Powr-Grip Co., Inc. 908 West Main St. Laurel, MT USA 59044	contactus@wpg.com	(1) 800-548-7341 (1) 406-628-8231

INTENDED FOR USE BY QUALIFIED SERVICE PERSONNEL

ENGINEERING DRAWINGS



**READ AND UNDERSTAND BEFORE ROUTING,
WIRING AND/OR ASSEMBLING**



908 W. Main • P.O. Box 368

Laurel, MT USA 59044

(1) 800-548-7341 • (1) 406-628-8231

www.wpg.com


**QUADRA-TILT LIFTER,
WITH ADJUSTABLE PAD
FRAME, AC-VOLTAGE**

Model numbers: MTA4LP6FACS, MTA6LP6FAC

WIRE LEGEND: CONTROLLED BY WIRING SYMBOLS DRAWING EXCEPT AS NOTED AND BELOW.		FILE DIRECTORY: FILE [SHEET]:		708 708B-W04 [B-W04]	
LINE STYLES AND WIDTHS FOR WIRE UNLESS NOTED OTHERWISE.		STANDARD			
N/A NOTE #1 N/A N/A 14AWG					
PRODUCT MANAGER: KELLY K.		DATE: 12/08/2011			
CHECKED: <i>CR</i>		10-13-15			
APPROVED: <i>Cann</i>		10/15/25			

NOTES:

- (1) SEE PUMP WIRING DIAGRAM FOR SPECIFIC WIRE GAUGE.
(2) WIRE THE CONNECTOR TO THE FOLLOWING CONVENTION:
(LABEL, SCREW COLOR: (FUNCTION) WIRE COLORS)
G, GREEN: (GROUND) GREEN WIRE
W, SILVER: (NEUTRAL) WHITE WIRE
X / L1, BRASS: (HOT) BLACK WIRE
Y / L2, BRASS: (HOT) RED WIRE (WHITE IF NO RED AND NO NEUTRAL)
Z / L3, BRASS: (HOT) WHITE WIRE (WHEN NO NEUTRAL IS REQUIRED)



WIRE LEGEND: CONTROLLED BY WIRING SYMBOLS DRAWING EXCEPT AS NOTED AND BELOW.		TYPE: STANDARD		FILE DIRECTORY: FILE [SHEET]:		855A-W01 [A-W01]		855	
LINE STYLES AND WIDTHS FOR WIRE UNLESS NOTED OTHERWISE.		THIS DRAWING IS THE PROPERTY OF IT IS LOANED WITH THE UNDERSTANDING THAT NEITHER IT NOR ANY INFORMATION CONTAINED THEREIN WILL BE COPIED, PUBLISHED OR TRANSMITTED TO OTHERS WITHOUT EXPRESS WRITTEN PERMISSION.		WOOD'S POWER-GRIP CO., INC. LAUREL, MONTANA U.S.A.		1500LB POWER-FILTER AC POWER SYSTEM		55CFM 120/240VAC WOBBLE-PISTON VAC PMP WIRING SCHEMATIC D855A-W01 [A-W01]	
PRODUCT MANAGER: KELLY K.		DATE: 12/01/2020		REVISION: 00.A		ECN NUMBER: 4960		ECN BY: CCH	
CHECKED: <i>OK</i>		12-08-20		SIZE: A		SCALE: NONE		EST. WEIGHT: N/A	
APPROVED: <i>Chp</i>		12-8-20		SIZE: A		SCALE: NONE		EST. WEIGHT: N/A	

