KEEP FOR FUTURE REFERENCE



P.O. Box 368 – 908 West Main Laurel, MT USA 59044 phone 800-548-7341 phone 406-628-8231 fax 406-628-8354

INSTALLATION

International Version

STOCK NUMBER: 29363AM



INSTRUCTIONS CANISTER RETROFIT KIT



READ ALL INSTRUCTIONS AND WARNINGS
BEFORE USING THIS PRODUCT



SPECIFICATIONS

Stock Number: 29363AM

Description: This canister provides easily-accessible storage for Operating Instructions

on WPG™ Equipment Products.

WARNINGS



Powr-Grip is pleased to offer the most reliable materials handling products available. However, due to the danger of improperly mounting the Instructions Canister on your equipment, certain precautions must be observed to protect the user and others.



Always wear personal protective equipment, such as safety glasses, when using power tools. Follow all regulatory workplace safety guidelines for your region and/or country.

Always check the equipment and determine where any vacuum hoses, wires, or other sensitive components may be positioned in the device before drilling. Failing to do so could result in serious damage to your equipment. For more information please contact Wood's Powr-Grip.


Never mount the Instruction Canister in a place where it might obstruct the operator's ability to effectively reach and manipulate any controls.

Never mount the Instruction Canister in a place where it might affect the equipment's ability to attach to a surface, if applicable.

Always remember that modifications to your equipment could affect its safety or function. Wood's Powr-Grip cannot be responsible for products that have been modified by the customer. For consultation, contact Wood's Powr-Grip (see LIMITED WARRANTY).

OPERATING FEATURES

Note: Components featured in the following instructions for assembling or using the Instructions Canister are <u>underlined</u> on their first appearance in each section.



Standard 29363AM shown.

1) INSTRUCTIONS CANISTER

2) 1/4-20 TRUSS HEAD BOLT

3) 1/4-20 JAM HEX NUT

ASSEMBLY

Assemble the equipment as directed in the ASSEMBLY section of its instruction manual. In addition, attach the <u>Instructions Canister</u> in an appropriate location, as follows:

 \bigwedge

WARNING: Do not drill into any vacuum hoses, wires, or other sensitive components.

TO ATTACH CANISTER TO METAL TUBING (RECOMMENDED)

- 1) Determine an optimal location on the equipment to mount the <u>Instructions Canister</u>, as follows: Make sure the canister will not block any controls or hamper the function of the equipment. The mounting location should not house any hoses, wires, or sensitive components. For vacuum lifters, the lift bar usually provides a desirable location.
- 2) Position the Instructions Canister on the equipment in the mounting location previously determined. Then mark the hole locations for the mounting bolts, and set the Instructions Canister aside.
- 3) Use a #7 bit to drill holes into the equipment at each mark made in the previous step and use a 1/4-20 tap to thread the holes. The holes should be drilled perpendicular to the mounting surface.
- 4) Align the two holes on the Instructions Canister with the two holes made in step 3. Thread the two 1/4-20 Truss Head Bolts into the holes. Medium strength thread-locker may be used to help secure the bolts.
- 5) Use a Phillips screwdriver to tighten the bolts securely. Do not over-tighten.

TO ATTACH CANISTER TO PLATE METAL (OR SIMILAR)

- 1) Determine an optimal location on the equipment to mount the <u>Instructions Canister</u> as follows: Make sure the canister will not block any controls or hamper the function of the equipment. The mounting location should not house any hoses, wires, or sensitive components.
- 2) Position the Instructions Canister on the equipment in the mounting location previously determined. Then mark the hole locations for the mounting bolts, and set the Instruction Canister aside.
- 3) Use a 9/32" bit to drill holes into the equipment at each mark made in the previous step. The holes should be drilled perpendicular to the mounting surface and penetrate to the other side of the material.
- 3) Align the two holes on the Instructions Canister with the two holes made in step 3. Insert the two 1/4-20 Truss Head Bolts into the holes.
- 4) Thread the <u>1/4-20 Jam Hex Nuts</u> onto the exposed ends of the bolts on the opposite side of the mounting surface from the canister.
- 5) Use a Phillips screwdriver and a 7/16" wrench to tighten the bolts securely. Do not overtighten.

OPERATION

The Instructions Canister is used to store Operating Instructions in a way that is easily accessible to the equipment operator. Unscrew the cap and remove the instructions to determine proper use and maintenance of the equipment. Return the instructions to the canister and replace the cap when finished.

REPLACEMENT PARTS LIST

Stock No.	Description	Qty
11011	1/4-20 Jam Hex Nut	2
10050	1/4-20 Truss Head Bolt	2

SERVICE ONLY WITH IDENTICAL REPLACEMENT PARTS
SUPPLIED BY OR APPROVED BY WOOD'S POWR-GRIP CO., INC.

LIMITED WARRANTY

Powr-Grip products are carefully constructed, thoroughly inspected at various stages of production, and individually tested. They are warranted to be free from defects in workmanship and materials for a period of one year from the date of purchase.

If a problem develops during the warranty period, follow the instructions hereafter to obtain warranty service. If inspection shows that the problem is due to defective workmanship or materials, Powr-Grip will repair the product without charge.

WARRANTY DOES NOT APPLY WHEN:

Modifications have been made to the product after leaving the factory.

Rubber portions have been cut or scratched during use.

Repairs are required due to abnormal wear and tear.

The product has been damaged, misused, or neglected.

If a problem is not covered under warranty, Powr-Grip will notify the customer of costs prior to repair. If the customer agrees to pay all repair costs and to receive the repaired product on a C.O.D. basis, Powr-Grip then will proceed with repairs.

TO OBTAIN REPAIRS OR WARRANTY SERVICE

For purchases in *North America*:

Contact the Technical Service Department at Wood's Powr-Grip Co. When factory service is required, ship the complete product--prepaid--along with your name, address and phone number to the street address hereafter.

For purchases in all other localities:

Contact your dealer or the Technical Service Department at Wood's Powr-Grip Co. for assistance.

Wood's Powr-Grip Co., Inc. 908 West Main St. / P.O. Box 368 Laurel, MT USA 59044

> phone 800-548-7341 phone 406-628-8231 fax 406-628-83